


# 973 ACCESSORIES

## SELECTOR/SWITCH ACCESSORY WITH TIMER



Code : **9730057**

Model : **ASC-051**

### Description

Accessorie for Door Entry System installations. Selector/switch accessory with timer activated by means of external control signal. Applications: activation of devices connected to the mains (lights, sirens), second electric lock.