

# 941 CAPTEURS

## TELERECEPTEUR AVEC 1 SORTIE DU RELAIS



Code : **9410335**

Modèle : **SNI-301**

### Description

Récepteur sans fil avec 1 sortie de relais qui se connecte à la centrale de chambre CHC. Il reçoit le signal d'activation des capteurs ou boutons sans fil associés et le notifie à la pièce centrale à laquelle il est connecté en émulant la pression d'un bouton pour la communication de l'activation des périphériques sans fil au système ALCAD NURSE CALL. Contrôle d'un seul appareil sans fil.

CODE	9410335
MODEL	SNI-301
Coding	Up to 32 transmitters can be programmed
Frequency	868,30 MHz
Channels	1
Power supply	12-24 V AC/DC
Power consumption	0.35 W standby at 12 V AC, 1.00 W standby at 24 V AC, 0.23 W standby at 12 V DC, 0.60 W standby at 24 V DC, 0.55 W relay switched at 12 V AC (without load), 1.50 W relay switched at 24 V AC (without load), 0.35 W relay switched at 12 V DC (without load), 1.00 W relay switched at 24 V DC (without load)
Operating modes	ON/OFF (2-button operation) ON/OFF (1-button operation) DEADMAN (maximum 36 seconds)
Outputs	1 potential-free relay contact (changeover)
Maximum contact load	1
Operating temperature	-20 °C to +60 °C
Dimensions	46 x 46 x 25 mm

