

903 MAST AMPLIFIERS

POWER SUPPLY 12/13/18 VDC 400 MA



Code : **9030213**

Model : **AL-245**

Description

Power supply unit for mast amplifier with SAT multiplexing. Voltage supply 12Vdc. If LNB control signal is received it powers both the amplifier and the LNB with the control signal coming from the SAT receiver. The output voltage is injected into the coaxial cable to power the amplifier and the LNB. The signal coming from the antenna is distributed to its two outputs. Protected against overloads and short circuits.

Applications

Individual terrestrial and satellite TV installations, digital and analogue, where mast amplifiers with SAT multiplexing are used.

Characteristics

Shielded zamak chassis, covered by an ABS plastic box. Power supply unit insulated from the high frequency circuit, complying with safety standards for both the installer and the user. Fixed to the wall by means of supplied wallplugs and screws. F type connectors.

| CÓDIGO-CODE-CODE | | 9030213 | |
|---|-----------------|---------|--------------------------------|
| MODELO-MODEL-MODÈLE | | AL-245 | |
| Entradas / salidas Inputs / outputs Entrées / sorties | | 1 / 2 | |
| Rango de frecuencia Frequency range Gamme de fréquences | Band | TV/SAT | |
| | MHz | 5-2150 | |
| Pérdidas de inserción Insertion loss Pertes d'insertion | dB | 5,0 | |
| Desacoplo entre salidas Isolation between outputs Découpage entre sorties | dB | ≥20 | |
| Tensión de salida Output voltage Tension de sortie | V _{DC} | 12 | - |
| | mA | 400 | - |
| Paso de corriente DC path Passage d'alimentation | V _{DC} | | STB Power 13/18 0/22 kHz |
| | mA | | 350 |
| Tensión de red Mains voltage Tension secteur | V _~ | 85-265 | - |
| | w | 5,8 | - |
| Temperatura de funcionamiento Operating temperature Température de fonctionnement | °C | -5..+55 | |
| Índice de protección Protection index Indice de protection | | IP 30 | |

Se debe cargar la salida no utilizada con una carga RS-275 (COD. 9120011).

The unused output should be loaded with an RS-275 (COD. 9120011) load.

La sortie non utilisée doit être chargée avec une charge RS-275 (COD. 9120011).

(1)Protegido contra sobrecargas y cortocircuitos. Si se produce un cortocircuito y no hay tensión de salida, desconectarlo de la red o quitarle la carga.

(1) Protected against overloading and short-circuits. If a short-circuit occurs and there is no output voltage, unplug it from the mains or take off the load.

(1) Protégée contre surcharges et court circuits. Si un court-circuit se produit, il coupe automatiquement sa tension de sortie, veuillez le déconnecter du réseau ou déconnecter sa sortie pour le réamer.